



FUJI IP SMT NOZZLE



Part Number (OEM)	Description
IPH - 3431	IP - SS NOZZLE Ø 1.0
IPH - 3421	IP - S NOZZLE Ø 1.3
IPH - 3411	IP - M NOZZLE Ø 2.5
IPH - 3401	IP - L NOZZLE Ø 4.0
IPH - 4511	IP - LL NOZZLE Ø 7.0 (WITH CAP)
IPH - 4520	IP - LL NOZZLE Ø 10.0 (WITH CAP)
IPH - 4531	IP - LL NOZZLE Ø 15.0 (WITH CAP)
IPH - 4541	IP - LL NOZZLE Ø 20.0 (WITH CAP)