



SONY DISPENS



Part Number	Description
-----	SONY DISPENSING NOZZLE 2D/2S \varnothing 0.8 / \varnothing 0.5
-----	SONY DISPENSING NOZZLE 2D/2S \varnothing 1.2 / \varnothing 0.9
-----	SONY DISPENSING NOZZLE 4D/1S \varnothing 0.8 / \varnothing 0.5